



INSTRUCTION

MOTOLED Brake Pressure Switch

Thanks for purchasing MOTO LED Brake Pressure Switch. Please read these instructions carefully before installation.

1. Important notes

- Do not modify this kit.
- This product is a critical part. Please install at your local dealer.
- Installation requires special knowledge and technique.
Haphazard installation may cause accidents or failure.

2. Installation

Please refer your service manual for removing and installation of stock parts.

- 1) Remove brake fluid and remove stock banjo bolts.
 Be careful not to spread brake fluid.
It damages painted surface.
- 2) Install this product with new washers.

Tightening torque : 30 Nm
- 3) Connect brake pressure wires and wires from motorcycle.
 Do not pull, twist, bend the harness beyond an acceptable extent. Doing so may cause wiring disconnection.
- 4) Fill brake fluid and bleed brakes.
- 5) Verify brake and brake lights work properly and check for brake fluid leakage after bleeding brakes.