

Installation Instructions

ZETA RADIATOR GUARD WR250R/X '07-

Thanks for purchasing ZETA RADIATOR GUARD.


Please check contents of kit and read these instructions carefully prior to installation.

1. Important notes

- Installation requires special knowledge and technique. Haphazard installation may cause accidents or failure.
- This kit can not be used with other optional parts if they interfere with this kit.

- Please do periodic check of the bolt and nut and retorquing them regularly.

2. Nomenclature and contents of kit



Contents of kit

- A. Radiator guard 1 ————1pc
- B. Radiator guard 2 ————1pc
- C. Shaft —————2pcs
- D. Plate —————1pc
- E. Spacer 1 —————2pcs
- F. Spacer 2 —————1pc
- G. M6x10 Tapered cap bolt ———6pcs
- H. M6x40 Flange bolt ————1pc


3. Installation

- Removing covers


- 1) Remove seat, right side panel, left side panel, right shroud, radiator cover and radiator.
*Refer your service manual for removing these parts from your bike.

- Installing radiator guards


- 1) Attach parts on radiator guard as shown in below figure.




- 2) Replace OE collar with E Spacer 1.




- 3) Attach radiator guard A.



- 4) Attach radiator guard B and plate D.



- 5) Reinstall OE radiator louver.



- Reinstalling covers

- 1) Reinstalling right side shroud, side panel and seat.
*Do not use OE radiator cover.
*Refer your service manual for these installations.