

Installation instructions

ZETA EXPLORER HANDLEBAR

Thank you for purchasing this ZETA product.

Please read these instructions carefully before installing.

1. Important note

- Please do not modify this product.
- This kit can not be used with other optional parts if they interfere with this product.

2. Installation

- Length adjustment function

- 1) Select a total length of 775 mm or 800 mm. (See Fig. 1)
*Do not cut the handle.
- 2) When installing the armor guard, make sure that the armor guard can be installed with the selected total length. (Refer to armor guard installation)
*Check before drilling holes in the switch box.
*Depending on the mounting method of the armor guard, only one of the full lengths may be attached.
- 3) After final setting, apply a removable low strength screw thread locker to the bar end adapter and fully tighten. (Specified torque 25 N·m)

Final setting

- Check the armor guard installation.
- Inner weight installation.
- Set the handle angle and lever position.
- Drilling holes for throttle position and switch box.

- Armor Guard Installation

- 1) Set the handle angle and attach using the included M8 bolt. (See Fig. 2)
*Do not use the anchors and bolts that come with the Armor Guard series.
- 2) Temporarily attach the bar end part, and while it is slightly movable, tighten each part with a good balance before mounting.
*If the bar end is tightened first, it will be difficult to attach the other mounts.
*Forcibly tightening the bar end (M8 bolt) may cause damage. Install the armor guard while adjusting the mount position and bolt tightening.

⚠ [Attention]




- After firmly tightening the bar end adapter, attach the armor guard.
- Adjust the position of the throttle grip so that the handle end is 2 mm to 3 mm out, and then drill a hole in the switch box.

- Installing the bar end plug

- 1) Open end grip without armor guard. Use the included bar end plug.
- 2) Please attach to the bar end adapter using the included M8 bolt.
*ZETA bar end plug series cannot be installed.

⚠ [Attention]

- Fully tighten the bar end adapter and then install the bar end plug.
- Adjust the position of the throttle grip so that the handle end comes out 2 to 3 mm, and make a hole on the switch box.




- Inner weight installation

- 1) The inner weight that decreases vibration can be easily attached and removed, and you can use it according to your preference.
- 2) Insert a hexagon wrench into the bar end adapter, insert a round bar into the hole in the inner weight, and tighten securely. (See Fig. 4)
*If it is not tightened enough, the weight will remain in the handle when removing the bar end adapter.
- 3) Be sure to apply grease to the O-ring part of the inner weight and insert it vertically into the handle to attach it. (See Fig. 4)

⚠ [Attention]

- When temporarily setting the handle length adjustment, remove the weight before starting work.
* After deciding the preference length, install the inner weight.
- When inserting the inner weight, resistance will occur in the handle threaded part. Please turn it back a little and repeat the insertion again.
* If grease is not applied, the O-ring may be damaged when it is inserted.
* If the O-ring is unexpectedly damaged, such as when the inner weight is removed, use a spare O-ring.

Fig. 4



- φ22.2mm mobile crossbar

- φ22.2mm, which is easy to attach the mobile holder, and also effective in decreasing vibration.
*The bar pad cannot be attached.


3. Inspection during use

- Check for slack of the bar end adapter.
*If loose, apply the thread locker again and tighten it.
- Check for loose mounting bolts on the mobile crossbar.
- Check if the throttle tube rotates smoothly.

4. Replacement

- Replace the replacement part if it is damaged or has degraded functionality. (See Fig. 5)
- Replacement Bar End Kit - - - - ZE07-0900 (Left and right set)
*Inner weight is not included.

Fig. 5



5. Handle height change/other related parts

- Handle height adjustment

- It is recommended to use the ZETA bar rise spacer/bar rise kit series for height adjustment.

- ZETA Adventure Windshield

- If the handle total length is set to 775mm and it cannot be installed due to interference with the brake banjo/hose, it will be necessary to reset to 800mm.